

Classic Vinkel vägg

Classic vinkel vägg

1 vinkel

2 knoppar

2 väggdistans

1 skruppåse: 2-pack skruvstift M6x80

med plugg

Monteringsanvisning:

1 Börja med att markera var du vill placera Classic kroklist. Tänk på att Classic vinkel vägg bygger cirka 208 mm ut från kroklisten. Följ monteringsanvisningen för Classic kroklist.

2 Sätt in skruvstift i de två hålen på vinkeln. Placera vinkeln i kroklisten och tryck försiktigt vinkeln mot väggen samtidigt som du säkerställer att den sitter rakt. Skruvstiften lämnar då märken på väggen som visar var du ska borra/skruva.

3 Skruva in skruvstiften. OBS! tänk på att skruva in skruvstiftet rakt. Sätt väggdistanserna på skruvstiftet. Placera sedan vinkeln i kroklisten och montera den på skruvstiften.

4 Skruva fast knopparna på vinkeln för att låsa den på plats.

Classic Vinkel wall

Classic vinkel wall

1 angle bracket

2 knobs

2 wall spacers

1 screw set: 2 pcs M6x80 screw studs

with wall plugs

Assembly instructions:

1 Start by marking where you want to place the Classic hook strip. Please note that the Classic angle wall bracket extends approximately 208mm from the hook strip. Follow the assembly instructions for the Classic hook strip.

2 Insert the screws studs into the two holes in the angle bracket. Place the angle bracket into the hook strip and gently press the angle bracket against the wall, making sure it is aligned straight. The screws studs will leave marks on the wall indicating where to drill/screw.

3 Screw in the screws studs. NOTE! make sure to screw the screws studs in straight. Place the wall spacers onto the screws studs. Then place the angle bracket into the hook strip and mount it onto the screws studs.

4 Fasten the knobs onto the angle bracket to lock it in place.

Essem
Design

+46(0) 371 194 10
info@essem.se
www.essem.se

