

Classic Tamburmajor

Classic tamburmaior

2 stukade rör

2 ostukade rör

6 knoppar

4 Fötter (stora knoppar)

4 möbelknapp M6xØ7

3 pinnskruv helgängad M6x60

6 pinnskruv helgängad M6x32

Monteringsanvisning:

1 Tryck i de krympta rören i de okrympta rören. Du har nu två delar som du ska sätta mot varandra.

2 Sätt i pinnskruv M6x60 i de översta hålen på tamburmajoren. Skruva på knopparna, men dra inte åt dem helt ännu.

3 Sätt i pinnskruv M6x32 i de två nedre hålen. Fäst dem med möbelknappar och dra åt ordentligt. Nu kan du även skruva fast knopparna som du tidigare lämnade lösa.

4 Skruva in pinnskruv M6x32 i fötterna och montera dem sedan under tamburmajoren.

Classic coat stand

Classic coat stand

2 crimped tubes

2 uncrimped tubes

6 knobs

4 floor knobs

4 furniture knob M6xØ7

3 fully threaded double-ended screw M6x60

6 fully threaded double-ended screw M6x32

Assembly instructions:

1 Insert the crimped tubes into the uncrimped tubes. You now have two parts that you press together.

2 Insert the M6x60 double-ended screws into the top holes of the coat stand. Screw on the knobs, but do not tighten them fully yet.

3 Insert the M6x32 double-ended screws into the two lower holes. Secure them with furniture knobs and tighten firmly. You can now also tighten the knobs you previously left loose.

4 Screw the M6x32 double-ended screws into the floor knobs, then attach them underneath the coat stand.

Essem +46(0) 371 194 10
Design info@essem.se
www.essem.se

